

# FRED MOBILITY INSTALLATION

## QUICK START GUIDE


Congratulations on your Fred Mobility purchase! Before you begin, check you have received the following items with your Fred Mobility package:



1 Fred Mobility handheld mobile device  
Motorola



1 Fred Mobility docking cradle/charger




yellow

1 Fred Mobility power supply




### ① Fred Mobility set up

- A** **Connect handheld device to cradle.** Connect the Fred Mobility handheld mobile device to the docking cradle.
- B** **Charge handheld device.** Connect the power supply to the docking cradle and plug it into an electrical outlet. Ensure electric outlet is ON.






# FRED MOBILITY INSTALLATION QUICK START GUIDE

Before you begin, check you have received the following items with your MSM310 Access Point package:



## ② Access Point set up

- A Connect power.** Connect the power supply together; plug it into the Access Point and then an electrical outlet. Ensure electrical outlet is ON.
- B Connect Access Point to Switch/Router.** Connect the RJ-45 Ethernet cable to the Access Point Ethernet port and then plug it into the Switch/Router Ethernet port.
- C Check light status indicators.** To ensure the Access Point is working properly, the following light indicators will display (on the back of the Access Point):
  -  **Power status light:** Shows a solid green light.
  -  **Ethernet status light:** Shows a blinking green light.
  -  **Radio wireless status light:** Shows a blinking green light.

